





INSTRUCTIONS FOR USE



. THE LOCK PRESET TO 0-0-0

. PUSH THE BUTTON 1. IN THE DIRECTION OF THE ARROW

. WHILE IN THIS POSITON SET EACH NUMBER TO YOU SELECTION



. RELEASE THE BUTTON AND YOUR NUMBER IS NOW SET

. TAKE CARE WHEN SETTING THE NUMBERS NOT TO RELEASE THE BUTTON